

# wozair

## **Product Summary**

Penthouse (Air Intake Separator) To draw air into the HVAC system from multiple

directions, and reduce the ingress of salt spray, rainwater and mist

Refrigeration Air Cooled Condenser /

#### Air Cooled Condenser Unit To reject heat to atmosphere from the cooling process

Sand Trap Louvre

To prevent sand from entering the HVAC system

Spin Tube Separator

To prevent sand from entering the HVAC system

Blast Tube Array

Passive device designed to protect both equipment and/or personnel from a blast/explosion

#### Filter / Bag Filter 6

To filter out solid particulate from the HVAC system

## Pre Heater

To prevent frost and increase the air temperature prior to its continuation through the HVAC system

#### Isolation Damper

To isolate/shut-off air flow within an area of the system

#### 9 Fire Damper

To prevent the spread of fire and/or smoke through the HVAC system

Non-Return Damper / Pressure Relief Damper

To prevent unwanted airflows against the intended airflow direction when the system is not in operation or maintain a pressure level in an area

## Modulation Control Damper

To regulate/modulate the flow of air through the HVAC system

#### **Control Panel**

To control and/or regulate the overall operation of the HVAC system

## Air Handling Unit

To recondition (heat/cool/filter) and circulate air as part of a HVAC system

#### Moisture Eliminator 131

To restrict the carry over of condensate on cooling coils

## Filter Bank

To filter/purify air prior to its continuation through the HVAC system

#### See Wozair datasheets for more information

All Wozair products are built to client specifications and can be customised to meet specific applications.

Heating / Cooling Coil

To heat and / or cool the air prior to its continuation through the HVAC system

#### Fans & Motors

Motors provide the necessary power to the fans to draw / blow the air through the Air Handling Unit

Attenuators (Silencers) 14

> To reduce noise produced by fan units and other equipment within the HVAC system

#### Diffusers

To direct the air into the room at the duct outlet

## Grilles

Terminal device mounted at the end of the duct to supply and extract air to and from the room

Extract Fan Skid

To draw stale, contaminated or dirty air from the room to discharge to atmosphere

Louvres 18

> To prevent ingress of rain, whilst allowing free passage for the air to exit

**Discharge Stack** 

To accelerate and exhaust hot air from the HVAC system to atmosphere







